



SAFETY REQUIREMENTS

- KEEP OUT OF REACH OF CHILDREN.
- The TORNADOR® Black can cause considerable noise from air pressure. Please wear hearing protection at all times.
- When using the TORNADOR® Black, small pieces of debris can be whirled into the air. Always wear protective goggles or glasses to prevent eye damage.
- The TORNADOR® Black nebulizes the cleaning liquid. Wear appropriate respiratory protection to prevent health hazards from inhalation.
- Use in well ventilated area.
- Do not exceed 90 psi.
- Do not use with acidic, flammable or combustible products; "USE ONLY WITH TORNADOR PRODUCTS."
- Do not point cleaning tool at face or body.
- Avoid breathing dust or handling debris that can be harmful to your health.
- Should you notice a tool malfunction, discontinue use and contact your supplier.
- Use caution when other people are in your surroundings and work area.
- Always disconnect the tool from the air supply when not in use and before changing accessories or when performing routine maintenance.
- Always check the tool for leaking hoses, loose fittings or damaged parts.
- We recommend that you never clean any safety related components with the TORNADOR® Black tool, i.e., safety belts, electrical or electronic modules.

AIR REQUIREMENTS

The TORNADOR® Black cleaning tool requires a constant air pressure between 5.5 and 6.3 bar 78 to 90 psi, for optimum performance. DO NOT EXCEED 90 psi.

CAUTION: Constant air supply rates vary depending on the size and power of the compressor. Always make sure tank and air lines are free from impurities, oil and water contamination.

INSTRUCTIONS FOR USE

Cleaning Fabric

1. Remove large debris and vacuum area to be cleaned.
2. Turn liquid air valve to upright position to deliver cleaning solution. Always use approved cleaning liquids.
3. Hold cleaning nozzle 1 to 3 inches from area to be cleaned. Fully depress trigger. Begin with overlapping motion over area to be cleaned.
4. Next turn valve to down position using just air and dry the area.

Cleaning Dashboard and Hard Surfaces.

1. Recommended air pressure set at 78 psi.
2. Turn liquid valve to straight up vertical position, using a overlapping motion, spray area to be cleaned.
3. Allow cleaning liquid to remain on surface for 10 -15 seconds.
4. Follow with air only by turning valve to the horizontal down position. Begin drying with overlapping motion followed with a soft dry towel.

▶ CONTINUED ON BACK PAGE