

CARE & MAINTENANCE

- Avoid dropping the gun on the floor, disconnect when not being used.
- Turn liquid valve to the horizontal position after use to avoid dripping from tip.
- Tighten the jar while holding the lid to avoid loosening or stripping gun assembly.
- Many cleaning solutions will have specific uses. Always use approved cleaning liquids in the TORNADOR® Black cleaning tool. Using high alkaline or acidic products are not recommended. Always follow manufacturer's dilution instructions. Neutral pH products and highly diluted water based products work best in the TORNADOR®. Always test in a small area.
- When cleaning with the TORNADOR®, use a microfiber towel to wipe any remaining debris or solution that needs to be wiped away.
- Keep the cone of the gun clean by removing the cone and rinsing frequently.
- Avoid excessive air pressure. Exceeding 90 psi can cause premature wear on the cone and assembly.



NOTE: After every use, place nozzle 2-3 inches into a bucket of soapy water while depressing the trigger once or twice to quickly remove dirt buildup in the cone. This will prevent premature wear.

TROUBLESHOOTING

PROBLEM

- Tip will not oscillate
- Tip moves slowly
- Tip drips fluid
- Will not dispense liquid

SOLUTION

- Check for low air pressure
- Check for dirt build-up and clean
- Keep liquid valve in the horizontal position when not in use
- Check pickup tube for debris and rinse out

LIMITED WARRANTY

"90 day limited manufacturer's warranty against manufacturing & part defects." Warranty will be voided, if it is used for anything other than the intended use of the TORNADOR® cleaning tool. Use of any products, other the TORNADOR® products, with or in the TORNADOR® cleaning tool, voids warranty.

